



Milwaukee 5262-21 Housing Assembly Replacement

Use this guide to remove the housing assembly in your Milwaukee 5262-21.

Written By: Adrien Andrade-Cain



This document was generated on 2020-01-21 03:53:49 PM (MST).

INTRODUCTION

Follow this guide to replace the Housing Assembly on your Milwaukee 5262-21 . You will be able to look at pictures, that will be useful in order to see which screws need to be removed.

TOOLS:

- [T20 Torx Screwdriver \(1\)](#)

PARTS:

- [Milwaukee 5262-21 Housing Assembly \(1\)](#)

Step 1 — Housing Assembly



- Remove the ten 19mm T20 Torx screws shown in red.

Step 2



- Remove the red Housing Assembly by lifting it up off of the tool.

To reassemble your device, follow these instructions in reverse order.