



# Milwaukee Hex Impact Driver 2656-20 Battery Replacement

This guide will demonstrate how to remove the battery on your Milwaukee Hex Impact Driver 2656-20.

Written By: BRYCE DICKERSON



This document was generated on 2020-01-03 03:59:59 PM (MST).

## INTRODUCTION

This guide will demonstrate how to replace the Battery on the Milwaukee Hex Impact Driver 2656-20. The step will cover the technique of removing the battery. There are no tools required. The repair is considered Very in difficulty and will take approximately 30 seconds.

## Step 1 — Battery



- Squeeze the red buttons on the battery.
- While squeezing the red buttons, slide the battery forward and out to remove it from the device.

To reassemble your device, follow these instructions in reverse order.