



Milwaukee Hex Impact Driver 2753-20 Battery Replacement

This guide will help you to replace the battery of the Milwaukee Hex Impact Driver 2753-20.

Written By: Kaylee Rose



INTRODUCTION

If your battery has malfunctioned or you need to charge and/or replace it, this guide will show you how to remove the battery from the device in one quick step with no tools required.



PARTS:

- M18 REDLITHIUM XC 4.0 Extended Capacity Battery Pack (1)

Step 1 — Battery



- While pinching the red locking buttons, pull the battery away from the front of the drill until the battery is fully removed.
- ① The battery is missing from this device so its removal is being mimed.

To reassemble your device, follow these instructions in reverse order.