



Missing valve of self-inflating mattress

When the valve of your self-inflating mattress is gone.

Written By: Stefan Hirschmeier



Step 1 — Missing valve of self-inflating mattress



- Just put one of the clips to keep food fresh over the corner of the mattress. It will keep the air even if you lay on it.

So easy.