



Motorola Adventure V750 Micro SD Replacement

Replacing a Micro SD card.

Written By: Kyle



Step 1 — Micro SD



- Locate back cover and the covers latch. Remove cover from the back of phone.

Step 2



- Locate sim card slot which is above the battery compartment.

Step 3



- With forefinger, continue to gently slide the sim card out to the right of the phone until card slot is empty.

Step 4



- Insert new sim card by sliding it underneath the sim card clip.

Step 5



- Put back cover on phone.

To reassemble your device, follow these instructions in reverse order.