



# Motorola C168 Battery Replacement

Instructs user on how to properly remove and replace a defective battery.

Written By: Christopher Wu





## PARTS:

- [Motorola C168 Replacement Battery \(1\)](#)

## Step 1 — Battery



- Turn the phone so its back is facing you.
- Press the release button on the back cover, while simultaneously pulling the cover down.
- Remove the back cover.

## Step 2



- Pinch the sides of the bottom of the battery and pull upward.

To reassemble your device, follow these instructions in reverse order.