



# Motorola Moto E4 (XT1762) Loudspeaker Replacement

This guide shows how to replace the loudspeaker of a Motorola Moto E4 (1762).

Written By: Tobias Isakeit



## INTRODUCTION

Use this guide to replace the loudspeaker of your Motorola Moto E4 (1762).

### TOOLS:

- [Spudger \(1\)](#)
- [Phillips #00 Screwdriver \(1\)](#)
- [iFixit Opening Picks set of 6 \(1\)](#)

## Step 1 — Back Cover



*(i)* Power off your phone before beginning disassembly.


- Insert a fingernail, or spudger, into the notch on the bottom right corner to start separating the phone unit from the back cover.
- Move to the bottom left corner to pry the phone out of the back cover.

## Step 2



- Lift the phone out of the back cover.

## Step 3 — Battery




- Use a fingernail or spudger to pry at the notch at the bottom end of the battery.
- Lever the battery out of its recess and remove it.

## Step 4 — Loudspeaker



- Remove the six 3.3 mm long Phillips #00 screws.

## Step 5



- Insert an opening pick between the loudspeaker and the frame to pry it up by twisting the opening pick.
- Remove the loudspeaker unit.

To reassemble your device, follow these instructions in reverse order.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).

Repair didn't go as planned? Check out our [Answers community](#) for troubleshooting help.