



Motorola Moto X4 Battery Replacement

Remove and replace your Moto X4 battery.

Written By: Brian Buchanan



INTRODUCTION

The official guide has been updated and can be found [here](#). This guide is archived for historical purposes.

This guide has one prerequisite since the display needs to be removed.

If your battery is swollen, [take appropriate precautions](#).

TOOLS:

- iOpener (1)
- Spudger (1)
- T4 Torx Screwdriver (1)
- T3 Torx Screwdriver (1)
- Tweezers (1)

PARTS:

- Motorola Moto X4 Replacement Battery (1)

Step 1 — Battery



- Remove the nine 3mm T4 Torx screws securing the silver plate to the device.
- Remove the eleven 2mm T3 Torx screws securing the plate to the device.

⚠ Incorrect placement of these screws during reassembly will cause permanent damage to your device's motherboard.

Step 2



- Use the flat end of a spudger to pry up the silver plate from both sides.
- Remove the plate from the device.

(i) Several clips hold the plate in place so there may be a clicking sound.

Step 3



- Use a pair of tweezers to gently lift the battery connector wire.

Step 4



- Use the flat end of the spudger to gently pry the battery from all sides from its casing.

⚠ The battery is secured to the motherboard with a mild adhesive. Peel slowly; be careful to not puncture or twist the battery.

To reassemble your device, follow these instructions in reverse order.

After completing this guide, [calibrate your newly-installed battery](#).