



Motorola Rival Battery Replacement

This guide will teach you how to replace the battery for the Motorola Rival

Written By: Sekani Paul



INTRODUCTION

Battery Replace

TOOLS:

- 2 Hands (1)

PARTS:

- Motoroloa Rival Replacement Battery (1)

Step 1 — Battery



- Locate the back side of the device

Step 2



- Locate the lever to release the back cover

Step 3



- Push down on the lever, while pulling the back cover away from the device

Step 4



- Place index finger an thumb on the battery and pull away from device.

Step 5



BATTERY FOR BT50

850mah

- Replace faulty battery with replacement battery and replace the cover on the device

To reassemble your device, follow these instructions in reverse order.