



Mt. Fury Roadmaster Tire Replacement

This guide is for replacing the tire inner tube on the Mt. Fury Roadmaster.

Written By: Samantha Rawlins



INTRODUCTION

If you determine that your tire is flat due to a ruptured or damaged inner tube this guide will help you replace the inner tube.

TOOLS:

- [Tire Levers \(1\)](#)

Step 1 — Inner Tube



- Flip the bicycle upside down so that the bicycle rests on the seat and handlebars. The bike should be able to stay standing on its own.

Step 2



- Using a 15mm wrench, loosen the axial nut.

Step 3



- Pull the chain slack and remove the tire.

Step 4



- Insert the flat side of the tire lever between the inside edge of the rim and the seal of the tire.
- Clip the tire lever to the nearest spoke.

Step 5



- Insert the second tire lever next to first and slowly slide it along the outside edge of the rim until one side of the tire is off the rim.

Step 6



- Re-insert the first tire lever to hook the opposite seam of the tire and repeat steps 3 through 5.

Step 7



- Remove the cap from the inner tube, and pull the valve stem out of the rim.

To install new inner tube, follow these instructions in reverse order.