



# NeuTab N9 Battery Replacement

This guide will inform you how to remove and replace the battery in the NeuTab N9 in the event of a failed or faulty battery.

Written By: Jake E



---

## INTRODUCTION

This guide will tell you how to replace the battery in the NeuTab N9. No prerequisite guides are required for this replacement.

---

### TOOLS:


- [Spudger](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Soldering Iron](#) (1)
-

## Step 1 — Battery





- ❗ Turn off your device before beginning these steps.
- Insert the plastic opening tool into the seam between the screen and the back of the tablet. Move the opening tool along the seam until the back of the tablet releases.

## Step 2




- Insert plastic spudger underneath the edges of the battery to pry it up and detach the adhesive.

## Step 3



- Completely remove the battery from the device by desoldering the red and black wires from the motherboard.

 Follow [these instructions](#) if you do not already know how to desolder.

To reassemble your device, follow these instructions in reverse order.