



Nexus 5 Battery Replacement

Prerequisite for disconnecting the battery.

Written By: Geoff Wacker



INTRODUCTION

Prerequisite-only.

TOOLS:

- [Spudger \(1\)](#)

Step 1 — Battery



- Use the flat end of a spudger to disconnect the battery connector.

To reassemble your device, follow these instructions in reverse order.