



Nexus 7 Power & Volume ZIF Connector Replacement

Prerequisite for detaching the Power & Volume ZIF Connector.

Written By: Brett Hartt





TOOLS:

- [Spudger](#) (1)
-

Step 1 — Power & Volume ZIF Connector



- Peel back the label covering the power and volume button ZIF connector.

Step 2



- Use the tip of a spudger to carefully flip up the retaining flap on the power and volume button ribbon cable ZIF socket.
- ⚠ Make sure you are flipping up the retaining flap, not the socket itself.
- Use the tip of a spudger to pull the power and volume button ribbon cable straight out of its socket.

This document was generated on 2019-10-21 02:49:59 AM (MST).

To reassemble your device, follow these instructions in reverse order.