



Nikon 1 J3 Battery Replacement

How to replace the battery of the Nikon 1 J3.

Written By: Austin Lackey



INTRODUCTION

This may be necessary if the device won't turn on, or is not lasting as long on battery power as it should.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

Step 1 — Battery



- Pull the tab on the bottom of the device

Step 2



- Pull the yellow tab away from the battery
- Pull the battery out

 The arrow on the battery should point down toward the lens

To reassemble your device, follow these instructions in reverse order.