



# Nikon 1 J3 Lens Replacement

How to replace the lens of the Nikon 1 J3.

Written By: Austin Lackey



## INTRODUCTION

The Nikon 1 J3 is designed to have a user replaceable lens. Here is how to replace it.

## Step 1 — Lens



- Locate the lens release button
- Push the lens release button and turn the lens clockwise

## Step 2



- Pull off the lens

 When putting on the new lens, be sure to line up the notches on the lens with the spaces on the camera.

To reassemble your device, follow these instructions in reverse order.