



Nikon Coolpix 775 Battery Replacement

How to remove and replace the battery for the Nikon Coolpix 775.


Written By: Suketu Patel



INTRODUCTION

Trying to figure out where the battery is located in the Nikon Coolpix 775? Follow this step-by-step guide to learn how you can remove the battery.

Step 1 — Battery



- Flip the camera, so the bottom is facing up.

Step 2



- Slide the gray latch to the open "pac-man" symbol.

Step 3



- Flip up the cover and remove the battery inside the slot.

To reassemble your device, follow these instructions in reverse order.