



Nikon Coolpix P4 Battery Replacement

Battery Replacement

Written By: Luke Baumann



INTRODUCTION

This guide will show you how to replace the battery.

Step 1 — Battery



- 'Click' the battery door over to the side.

Step 2



- Open the battery door. Inside is the memory card and the battery.
- Click over the orange tab and take out the battery.
- Close the battery lid by pushing it down and sliding it back.

To reassemble your device, follow these instructions in reverse order.