



# Nikon Coolpix P510 Battery Removal Replacement

This is a preliminary guide for safety, so that the user doesn't get shocked while taking apart other pieces of the camera.

Written By: Brian Hulsey



This document was generated on 2019-09-23 03:54:22 PM (MST).

## Step 1 — Battery Removal



- Flip the camera over and push the tab on the battery cover to open the battery compartment.

## Step 2



- Push the little yellow tab to allow the battery to slide out.
- With the tab pushed out, pull the battery out.

To reassemble your device, follow these instructions in reverse order.