



Nikon Coolpix S33 Front Cover Replacement

If your front-glas is broken you could replace it with a front from another S33 or directly replace the glas.

Written By: Bernhard Seibert



 **TOOLS:**

- [T5 Torx Screwdriver \(1\)](#)
- [JIS #000 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

 **PARTS:**


- [New Item \(1\)](#)

Step 1 — Remove Back Cover



- Follow the instructions from the Guide: Nikon Coolpix S33 Back Cover Replacement

Step 2 — Remove 3 Screws



- Remove all 3 Screws

Step 3 — Remove the inner part



- Pull the inner part out carefully.

Repeat the steps in order to reassemble your device.