



Nikon Coolpix S800c Battery Replacement Guide

This guide is meant to help owners correctly replace the battery for the Nikon Coolpix S800c without damaging the camera.

Written By: Ilyasah Muhammad



INTRODUCTION

This guide will teach owners how to replace their battery if it is defective or exhibits signs of a declining battery life.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

PARTS:



- [Nikon Coolpix S800c Battery \(1\)](#)

Step 1 — Battery



- Using plastic tool, open battery cover located on the bottom, left of the camera, if the camera lens were facing you.

Step 2



- Remove battery from battery slot.
- Place new battery in slot and make sure the negative side is on the left side.

(i) Battery Access Door was unavailable

To reassemble your device, follow these instructions in reverse order.