



# Nintendo 3DS Back Cover Replacement

Back cover removal.

Written By: David Hodson



## INTRODUCTION

Removing the back cover to access the battery and internals of the Nintendo 3DS.

### TOOLS:


- [Phillips #00 Screwdriver](#) (1)

## Step 1 — Back Cover



- Unscrew the four Phillips #00 screws along the top of the back cover.
- (i)* The screws are held in place by locking washers, and will not come out of the back cover.
- !** The comments section is full of unlucky souls who will tell you that the screws here through step 4 will strip incredibly easily. Press down fairly hard, and go slow.

## Step 2



*i* Hold the device in one hand and turn it over.

- Grab the top edge of the back cover with your opposite hand so that the cover does not fall back into place.

*i* Flip the 3DS over again so that the back cover is facing up.

- Pull the back cover up and away from the rest of the device to remove it.

To reassemble your device, follow these instructions in reverse order.