



# Nintendo 64 Rumble Pak Battery Replacement

This guide will show you how to replace the batteries and check for corrosion in your N64 Rumble Pak.

Written By: Carly Bowen



## INTRODUCTION

Does your Rumble Pak no longer vibrate? Learn how to check for corrosion and replace the batteries in your Rumble Pak to continue enjoying the ultimate gaming experience.

### TOOLS:

- Q-Tips (1)
- Flathead Screwdriver (1)

### PARTS:

- AAA Battery (2)

## Step 1 — Rumble Pak Battery



- Remove the Rumble Pak from the controller by pressing the release button and pulling the Rumble Pak out.

## Step 2




- Remove the battery cover from the Rumble Pak by pressing the tab and pulling the cover up.

## Step 3



- Press each battery toward the spring, then pull toward you to remove the batteries from the Rumble Pak.
- ⚠ When inserting the new batteries, make sure the positive (+) end of the battery touches the flat piece, and the negative (-) end touches the spring.

## Step 4



- Check for corrosion around the springs and the flat plate where the batteries touch.
- ⚠ Do not touch the corrosion. It may be battery acid.
- Use a flat head screwdriver to chisel away the corrosion, and use a Q-tip to wipe it clean.
- ⚠ Do not use water to wet the Q-tip, as water can damage the Rumble Pak.

To reassemble your device, follow these instructions in reverse order.

