



Nintendo 64 Controller Teardown

Teardown of the standard controller for the Nintendo 64.

Written By: Ian



 **TOOLS:**

- **Phillips #1 Screwdriver** (1)
- **Phillips #0 Screwdriver** (1)

Step 1 — Nintendo 64 Controller Teardown



- Behold the glorious retro controller face, then forget about it because you will flip the controller for the rest of the teardown.
- Use the size #1 Philips to remove the 7 screws on the back of the controller.
- Use the size #0 Philips to remove the smaller screws in the controller pak slot.

Step 2



- Remove the back plate. You can now see the:
 - Power Input
 - Game Pak Slot
 - Trigger Button Assemblies
 - Z Button Assembly
 - Joystick Module

Step 3



- Using a spudger or similar tool, carefully pry the Z button assembly from the joystick module.
- Remove the 3 size #0 screws holding in the joystick module.
- Remove the joystick cable from the main board.

Step 4



- Remove the joystick module.

(i) This particular module is a third party replacement. Yours may look different.

Step 5



- Remove the main board and trigger assemblies.
- Your controller is now fully disassembled!