



Nintendo 64 Top Cover Replacement

Written By: bbdiamond13



INTRODUCTION

This guide will assist in removing the top cover of the Nintendo 64.

TOOLS:

- Gamebit 4.5mm (1)
- Metal Spudger (1)

Step 1 — Top Cover



- Remove the expansion pack cover by pushing in the tab and pulling out.

Step 2



- If your system uses a jumper pack, the same procedure applies to remove it.
- A small spoon can be used in place of a spudger.
- Lever the expansion pack out using a metal spudger.

Step 3



- Remove the six screws on the bottom side indicated in the example with a gamebit head or screwdriver.

Step 4



- Remove the two front feet of the N64.

Step 5



- Rotate to top side up and lift off top cover.

To reassemble your device, follow these instructions in reverse order.