



# Nintendo Wii U Pro Controller Battery Replacement

This guide will help you to successfully access and replace the controller's battery.

Written By: Chris Felder



## INTRODUCTION

This guide shows users how to replace defective and/or broken batteries in their Wii U Pro controller.

### TOOLS:

- Spudger (1)
- 64 Bit Driver Kit (1)

### PARTS:

- [Nintendo 3DS Battery](#) (1)

## Step 1 — Battery



- Turn the controller over to reveal the battery cover.

## Step 2



- Turn the controller over to reveal the battery cover.
- Use the J000 screwdriver to remove the screw that secures the battery cover.

## Step 3



- Turn the controller over to reveal the battery cover.
- Use the J000 screwdriver to remove the screw that secures the battery cover.

## Step 4



- Remove the battery from the controller by inserting the plastic spudger into the small gap on the bottom right of the battery.
- Use the spudger as a lever to pry up and remove the battery from the compartment.

## Step 5



- When the battery is removed and the compartment is emptied, a new battery can be inserted (if needed).

## Step 6



- When the battery is removed, use the Y0 screwdriver to remove the eight 5.5mm screws.
- Four screws are located within the battery compartment (circled in red).
- Four screws are located outside of the battery compartment (circled in orange)

## Step 7



- Once all of the screws are removed, separate and then remove the bottom half of the controllers shell from the top half.

## Step 8



- As indicated in the picture above, the joystick is easier to replace when you move the right trigger and sensor out of the way.
- Use the J0 screwdriver to remove the 4mm screw (circled in orange).