




# Nixon Mission Android Wear Battery Replacement

Disassemble Nixon Mission Android Wear for battery replacement.

Written By: Mauricio Ambrosio




## INTRODUCTION

Batteries tend to lose capacity over time. This guide will show you how to replace the battery of your Nixon Mission Android Wear.

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)

## Step 1 — Battery



- Remove 4 4.5mm Phillips head screws from back side of watch using PH00 Phillips head.

## Step 2



- Remove the back plate of watch.

## Step 3



- Unclip 5 latches from motherboard using a plastic spudger.

## Step 4




- Remove the 2 3.0mm screws from motherboard using PH00 Phillips head.

## Step 5




- Carefully remove motherboard & internal screen.

## Step 6



- Remove from the motherboard the connector with the four cables.
- Pull the cables upward and the motherboard downward as shown in the picture.

## Step 7



- Carefully remove the battery from the watch.

To reassemble your device, follow these instructions in reverse order.