




Nobis NB07 Speaker Replacement

Use this guide to replace the speaker of your tablet.

Written By: Daniel Gomero




INTRODUCTION

You will be able to use this guide to successfully replace a faulty speaker on your tablet. To do so, you will need to disassemble your tablet and use soldering tools.

TOOLS:

- [Electrical Tape in 6 Assorted Colors \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Soldering Workstation \(1\)](#)
- [Spudger \(1\)](#)
- [Low Adhesive Glue \(1\)](#)

Step 1 — Opening the case



- Look towards the topside of the tablet, where the power button is located.
- Insert a plastic opening tool in the crack between the two parts of the case.
- Move it gently back and forth to open the case.

Step 2



- With the plastic opening tool in the opening between the two sides of the case, slide the tool along the tablet's border to separate the two sides completely.


⚠ Be careful when you separate the two halves. Open the case from the opposite side of the camera, there is a cable connecting both halves of the case.

Step 3 — Replacing the battery



- Remove the tape holding the battery in place.


Step 4



- Insert the flat end of the spudger tool in the crack beneath the battery.
- Move the spudger tool carefully side to side to remove the glue that is holding the battery in place.

(i) This is a soft battery, so a little bending is expected.


Step 5



- After the battery is unglued, locate the cables that connect it to the motherboard.

ⓘ Annotate where each color goes to make the reassembly easier.

Step 6




- Desolder the cables with a soldering iron and use a desoldering braid to remove the solder.

ⓘ Review the [iFixit soldering guide](#) if you need help soldering.


 You can now remove the battery.

Step 7 — Removing the speaker



- Remove the tape holding the speaker in its socket.



Step 8



- After you remove the tape, remove the speaker from its socket. You can place the speaker on one side of the tablet to have more freedom.
- Look for the place where the speaker's cables meet with the motherboard.

ⓘ Annotate where which color goes to make the reassembly easier.

Step 9



- Use a soldering iron to desolder the cables and extract the solder using a desoldering braid.
- ⓘ Review the [iFixit soldering guide](#) if you need help soldering.
- ⭐ You can now remove the speaker.

To reassemble your device, follow these instructions in reverse order.