



Nokero N222-Huron Clear Cover Replacement

Removing and replacing the clear plastic cover to access and to weather-proof and protect the device.

Written By: Vinny Capone



INTRODUCTION

If the clear plastic cover of your Nokero N222-Huron becomes cracked or dirty, removing it for replacement or cleaning may help.

Step 1 — Clear Cover



- Grasp the clear cover and the white housing and twist the cover counter-clockwise.

i The lid may hold fast, but it will come off with some firm twisting.

Step 2



- Lift the lid from the device

i It may be helpful to use a spudger to pry under the lid if there is difficulty in getting a good grip on the smooth plastic.

To reassemble your device, follow these instructions in reverse order.