



Nokia 2610 Battery and Sim Card Replacement

How to replace the battery and the Sim card in the Nokia 2610.

Written By: Taylor Hinsdale



INTRODUCTION

This guide will show you how to replace a faulty battery in your phone and how to replace a Sim card.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

Step 1 — Battery and Sim Card



- Place your thumb on the middle of the back cover and push it toward the bottom of the phone to slide the cover off.

Step 2



- Use a plastic opening tool (or your finger) to gently pry the battery out of the battery slot on the back of the phone.

Step 3



- Lift the metal sim card holder (at the bottom of the battery slot) up and carefully pry the sim card out of its slot with a plastic opening tool or your finger.
- After removal, lower the metal sim card holder into its original position.

To reassemble your device, follow these instructions in reverse order.