



Nokia 3100b SIM Card Replacement

How to replace a Nokia 3100b SIM card.

Written By: Sterling Fuentes



INTRODUCTION

How to remove your SIM card from the Nokia 3100b.

Step 1 — Battery



- Make sure your phone is turned off.

Step 2



- Press the button on the back of the phone and slide the back panel off.
- Remove the battery by pulling it from the phone.

Step 3 — SIM Card



- Gently pull back the small metal frame holding the SIM card into place, and lift open the frame.

Step 4



- Retrieve your SIM card.

To reassemble your device, follow these instructions in reverse order.