



Nokia 5310b XpressMusic Battery Replacement

This will show you how to install/replace the Nokia 5310b XpressMusic Cellphone Battery.

Written By: Max Kirby



Step 1 — Battery



- Slide the back cover down with your thumb.
- *Note: the battery cover is not shown in this picture

Step 2



- Gently lift the battery with a fingernail and remove it from its housing.
- *Note: the battery may be replaced or repaired at this step

To reassemble your device, follow these instructions in reverse order.