




Nokia 6030 LCD Screen Replacement

Written By: Spencer Woodworth



INTRODUCTION

Replacing LCD Screen.



TOOLS:

- [T6 Torx Screwdriver](#) (1)
-

Step 1 — Battery



- Press the grip on the back of the phone and slide the rear housing down towards the bottom of the phone.

Step 2



- Use your fingernail and gently pull the the bottom of the battery up.
- Lift out battery and remove.

Step 3 — SIM Card




- Use your fingernail to lift the metal cage up.
- Remove SIM card.

Step 4



- Close the metal cage.

Step 5 — Front Cover



- Pull the top casing up after inserting thumbs under the two tabs labeled with the arrows. then slowly rotate up and over the screen.

Step 6



- After removing the top cover, turn the phone over so the screen is facing upwards.

Step 7



- Lift the front off the phone by pulling above the arrows.

Step 8 — LCD Screen



- Remove the six screws with a T-6 Torx screwdriver.


Step 9



- Gently lift the top of the screen up.

⚠ Be cautious of loose parts.

Step 10



- Gently pull up on the grey plastic tab.

To reassemble your device, follow these instructions in reverse order.