



Nokia E61i Battery Replacement

This guide will illustrate how to remove the battery in the Nokia E61i.

Written By: Christopher Patton



INTRODUCTION

This guide will illustrate how to remove the battery in the Nokia E61i.



PARTS:


- Nokia BP-4L standard battery. (1)

Step 1 — Battery




- To access the battery you must remove the back cover. Press the tab on the bottom of the cover in so that the back cover plate can slide over it.
- Now slide the back cover off of the phone.

Step 2



- Once the backplate is removed, look to the bottom-left corner of the phone where there is a spot to remove the battery.

Step 3



- Use your finger to lift the battery out.
- *i* The E61i uses a Nokia BP-4L standard battery.

To reassemble your device, follow these instructions in reverse order.