




# Nokia Lumia 620 Loudspeaker Replacement

How to disassemble the phone and replace the Loudspeaker / Buzzer / Ringer.

Written By: ZFix



## INTRODUCTION

How to disassemble the phone and replace the Loudspeaker / Buzzer / Ringer.

### TOOLS:

- T4 Torx Screwdriver (1)

### PARTS:

- Nokia Lumia 500 610 620 720 820 920 925 (1)

## Step 1 — Loudspeaker



- Switch off the phone, remove the battery and SIM (Memory) card.
- The lower back cover is held by 3x T4 Torx screws.

 The screws are of two types!

## Step 2



- The Loudspeaker is on the lower back cover.

To reassemble your device, follow these instructions in reverse order.