



Nokia Windows 8 Phone All Models - Factory Reset

Nokia Windows 8 Phone All Models - Factory Reset

Written By: ZFix



INTRODUCTION

If you have problems with the OS, forgotten screen lock or you want to erase all your personal data, you can do Factory / Hard Reset.


Nokia Lumia - Icon, 520, 525, 530, 620, 625, 630, 635, 720, 730, 820, 830, 920, 925, 928, 930, 1020, 1320, 1520,

Microsoft Lumia - 430, 435, 532, 535, 540, 550, 640, 950, 1030,

HTC Windows Phone - 8S, 8X

[video: <https://www.youtube.com/watch?v=DMLPHnqwICQ>]

Step 1 — Nokia Windows 8 Phone All Models - Factory Reset



- Turn off the phone.
- Press and hold the Volume Down and the Power buttons.
- When you feel a vibration, release only the Power button,
 - or,
- press and hold the Volume down button and connect the charger.
- You will see an exclamation mark.

Step 2



- Press the keys in this order:
 - Volume Up
 - Volume Down
 - Power
 - Volume Down
- The phone will reset and restart. This may take a few minutes.
- .
- **Did you do it successfully?**

To reassemble your device, follow these instructions in reverse order.