



# **Nook Simple Touch with GlowLight screen Replacement**

Part of the screen is damaged and display is unreadable.

Written By: Woody Russ

To reassemble your device, follow these instructions in reverse order.