




NuVision 10.1 Atom Speaker Replacement

If you experience problems with the sound or speaker quality, follow this guide to replace them in your NuVision 10.1 Atom.

Written By: Carly Daniele




INTRODUCTION

How to access and replace the speakers. Make sure to carefully handle any wires so they are not damaged.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Cover




- Turn the device screen side down.
- Carefully remove the back piece with the iFixit opening tool.

Step 2




- Remove the yellow tape covering the motherboard gently with your fingers.

Step 3 — Speaker



- Carefully remove silver tape with your fingers.

Step 4



- Remove speakers gently using your fingers, they pop out easily.
- Disconnect cords attached to the speaker from white pod.

To reassemble your device, follow these instructions in reverse order.