



# Olympus Pen E-PL7 Battery Replacement

This guide will help you replace the battery in the Olympus Pen E-PL7.

Written By: Kelsea Weber



## INTRODUCTION

Camera not turning on? The battery may need to be recharged or replaced. Use this guide to replace the battery and get back to taking awesome photos!

## Step 1 — Battery



- Turn the camera upside down.
- Push the grey tab to the right to open the battery compartment.
- Pull out the battery.

**(i)** The battery is not shown in these photos.

To reassemble your device, follow these instructions in reverse order.