



Olympus SZ-12 Back Case Replacement

How to replace the Back Case of the Olympus SZ-12

Written By: Samuel Hays



INTRODUCTION

You will need a clean, well-lit area, an iFixit repair kit including the specialized screw driver, along with the Phillips #000 bit. We also recommend you have an organization tray in order to keep track of all the screws you will be taking out.

TOOLS:

- [Phillips #000 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Back Case



- Remove nine 4.45mm Phillips #000 screws from the outside of the case.

Step 2



- There are four screws to take out on the bottom of the camera.

Step 3



- There are three screws to take out on this side.

Step 4




- There is one screw to take out on this side.

Step 5



- There is one hidden screw inside the HDMI port.

Step 6



- Using the blue plastic opening tool, wedge open and remove the case.

To reassemble your device, follow these instructions in reverse order.