



# Olympus Stylus Tough TG-2 iHS Battery Replacement

This guide will illustrate how to access and remove the battery.

Written By: Yushu Liu



## INTRODUCTION


Battery dead? It may be time to replace it. This guide will walk you through the simple steps to access and replace your battery.

## Step 1 — Battery



- Locate the two locking tabs on battery/card cover onthe bottom of the camera.
- Slide the tab labeled lock to show orange.
- Slide the battery/card cover lock to revile orange and the door will spring open.

## Step 2



- Press the red tab to eject the battery.
- *i* Take note of the orientation of the battery. It wont operate if inserted upside down .

To reassemble your device, follow these instructions in reverse order.