



One Education Infinity One Top Case Replacement

This guide will show you how to remove the top cover of the One Education Infinity:One laptop.

Written By: Taylor Bratsch




INTRODUCTION

This guide will show you how to remove the top case of the One Education Infinity:One laptop. This should be used to replace a damaged top cover, or to gain access to internal components for more complex repairs.

TOOLS:

- [Jimmy](#) (1)
- [iFixit Opening Picks set of 6](#) (1)

Step 1 — Top Case



- Insert a Jimmy or other prying tool into the seam between the screen and back case.
- Trace around the edges until all clips are released.
- Lift the back case away from the tablet.

To reassemble your device, follow these instructions in reverse order.