




# P775DM3 hard drive replacement (mass storage)

Written By: Felice Suglia




## Step 1 — Battery




- Unlock the lock marked in red.

## Step 2



- Lift up the battery while unlocking the lock marked in red.

## Step 3 — Disk access






- Unscrew the two screws circled in red
- Slide the plate in the direction of the arrow

## Step 4



- Lift the plate

## Step 5 — Hard Disk (Mass Storage)



- Unscrew the screw circled in red
- Lift the disc with the green tab
- Remove the disc in the direction of the arrow

To reassemble your device, follow the instructions in reverse order.