



Palm Pre Battery Replacement

Guide to replacing the battery.

Written By: noha



 **TOOLS:**

- [Spudger \(1\)](#)

Step 1 — Battery



- Make sure your Palm Pre is turned off before disassembling the phone.
- Snap off the back panel to reveal the battery.

Step 2



- Carefully pull up on the tab to remove the current battery.

To reassemble your device, follow these instructions in reverse order.