



Palm Treo 650 battery and stylus replacement

Written By: cgood



INTRODUCTION

This guide will show how to separate the battery from the phone.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)
- [T5 Torx Screwdriver](#) (1)

Step 1 — Battery



- Position the phone so the screen faces down.
- Remove the stylus found on the back of the phone.

Step 2



- To remove the battery cover, hold down the button in the middle of the phone's back.
- Slide the cover down to remove. Set the cover aside.

Step 3



- Lift the edge of the battery, separating contact points, and pull out as pictured.

To reassemble your device, follow these instructions in reverse order.