



Palm m 100 Reset

This guide will enable the user to reset the device.

Written By: Anne Carey



INTRODUCTION

If the users device will turn on, but it is not functioning properly, this guide will assist in resetting the device.

TOOLS:

- Paper Clip (1)

Step 1 — Palm m 100 Reset



- Locate the reset button on the back rear cover labeled “reset” just above the battery cover.

Step 2



- Open a standard paper clip and insert into the end into the hole for the button. Gently press the button.

To reassemble your device, follow these instructions in reverse order.