



Panasonic ER-GN30-K Battery Replacement

Replace a dead battery in a Panasonic ER-GN30-K.

Written By: Alejandro Garabatos



INTRODUCTION

Is your Panasonic ER-GN30-K battery dead? Here is a quick guide on how to swap it out for a fresh one.

Step 1 — Battery



- Remove the back battery cap from the device by twisting it to the unlock position and pulling.

Step 2



- Remove the dead or corroded battery by pulling the uncovered end out and sliding the rest of the battery out.

 If the battery is corroded, do not touch it with your bare hands. Residual battery acid can burn your skin,

To reassemble your device, follow these instructions in reverse order.