



Panasonic ES-RF31 Battery Replacement

This is a guide how to change the battery of a Panasonic ES-RF31 razor.

Written By: Daniel



INTRODUCTION

This guide shows you how to replace the battery of the Panasonic ES-RF31. You can find more specs here: <http://www.panasonic.com/de/consumer/koe...>

TOOLS:

- [64 Bit Driver Kit \(1\)](#)
- [Jimmy \(1\)](#)

Step 1 — Battery




- Loose the screw at the bottom part of the razor

Step 2 — Removing the Backcover




- Slide the cover from top to bottom

Step 3 — Removing the Batterycover



- Loosen these eight screws

Step 4 — Removing the Battery Cover



- Insert an opening tool into the gap
- Gently remove the battery cover

Step 5 — Removing the Battery



- Gently remove the battery

To reassemble your device, follow these instructions in reverse order.