



Panasonic GU87 SIM Card Replacement

Use this guide to replace or install a new SIM Card.

Written By: Daniel





PARTS:

- [SIM Card \(1\)](#)

Step 1 — Battery



- Place your hands on the phone as shown in picture. Slightly pull the tab away from the phone with your thumb.

Step 2



- Lift the battery up from the phone as shown. Replace with a new battery if the old battery has become worn out.

Step 3 — SIM Card



- Using your index finger, slide the SIM card into the slot.

To reassemble your device, follow these instructions in reverse order.