



# Panasonic Lumix DMC-G5 Battery Replacement

Use this guide to replace your Panasonic Lumix DMC-G5 Battery.

Written By: Khairul Samsudin



## INTRODUCTION

This guide shows the steps to remove the Panasonic Lumix DMC-G5 battery from the camera if the battery is damaged or to remove the battery to recharge.

## Step 1 — Battery



- Push the slider to "open"

## Step 2



- Push the top to release the battery

## Step 3



- Remove the battery.

To reassemble your device, follow these instructions in reverse order.