



Panasonic VDR-D220 DVD Battery Replacement

This guide will assist you in replacing the battery on a Panasonic VDR-D220. If you find that the battery has too many charge cycles it needs to be replaced

Written By: Brandon Gregoire





PARTS:

- <https://www.ebay.com/itm/Fits-Panasonic-VDR-D220-Li-ion-Camcorder-Battery-2100mAh-7-2v/192888208458?hash=item2ce9087c4a:g:9zIAOSwTfNcsOKw> (1)

Step 1 — Battery



- Slide the battery release lever found on the bottom of the camera in the direction of the front of the camera.

Step 2



- Remove the battery from its holding spot/where it mounts to the camera.
- Inspect the contact points and be sure that there isn't any debris that could be resulting in loss of current flow.

To reassemble your device, follow these instructions in reverse order.